
# Whirlpool

### **TOP AND CABINET PARTS**

AUTOMATIC WASHER



#### **TOP AND CABINET PARTS**

For Models: LSQ9549LQ0, LSQ9549LW0, LSQ9549LG0 (Designer White) (White/Grey) (Biscuit/Gold)


Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
•	LIT3956025	Installation
		Instructions
	LIT3955869	Use & Care Guide
	LIT3955561	Energy Guide
	LIT3955499	Wiring Diagram

#### **Following May Be Purchased**

#### DO-IT-YOURSELF REPAIR MANUALS

	LIT4313896	Manual, Washer Do-It-Yourself
2	3955792	Top White
	3955792	
2	62750	Biscuit
3	02730	Spacer, Cabinet To Top (4)
4	357213	Nut, Push–In (2)
5	337213	Cabinet
J	63424	White
	3954357	Biscuit
6	62780	Clip, Top & Cabinet
·	02.00	& Rear Panel (2)
7	3976348	Cabinet –
		Sound Damper
8	3400611	Screw,
		Lid Switch (2)
9	3357011	Screw, 10-16 x 1/2
10	8054939	Seal, Lid
11	8054980	Switch, Lid
13	355274	Screw, Lid Hinge
		Mounting (4)
15	8055257	Hinge, Lid (L.H.)
16	8055256	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	8319539	Bearing, Lid
		Hinge (2)
19	00=0010	Lid
	3956016	White
00	3956017	Biscuit
22 28	3351614	Screw, Ground
∠ŏ	3390631	Screw,
31	3955788	10–16 x 3/8 (4)
32	3955788 8519517	Cover, Dispenser Dispenser, Bleach
<b>J</b> Z	0019017	Dispenser, Dieach


#### **CONTROLS AND REAR PANEL PARTS**



### **CONTROLS AND REAR PANEL PARTS**

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water	16		Cap, End (L.H.)	40	3955775	Medallion
		Inlet Hose (4)		8271365		44	0074045	Knob, Timer
2	2400072	(1–1/16 x 5/8)	17	8271368	Clip, Capacitor			(For LSQ9549LQ0) (For LSQ9549LW0)
2 3	3400073	Screw, Ground Hose, Water	18		Valve, Water			(For LSQ9549LG0)
3		Inlet (2)	'	0002101	Mixing	45	0010010	Dial, Timer
	3949374	Blue Coupler	19	3976286	Shield, Capacitor	_	8271351	(For LSQ9549LQ0)
		Red Coupler	20		Mini-Buzzer		8316539	(For LSQ9549LWO)
4	9740848		21		Clamp, Hose		8316547	(For LSQ9549LG0)
5		Strap, Console (2)	22	3357328	Hose, Vacuum	47	0074000	Knob, Control
6		Panel, Rear		074500	Break			(For LSQ9549LQ0)
7		Pad, Rear Panel	23 24		Clamp, Hose			(For LSQ9549LW0)
8	3951609	Hose, Drain	24 25		Break, Vacuum	49		(For LSQ9549LG0) Screw, 8–18 x 1.25
	661577	(4 ft.)	25	0319200	Support, Rear Panel	49	300320	(Panel to Top)
	001377	Hose, Drain (9 ft.)	26	661606	Capacitor,	50	62863	Screw, 10–16 x 3/8
		(Not Included)	20	001000	Motor Start	51	02000	Cap, End (R.H.)
	3357090	Extension	27	3366912	Clamp, Hose	0.	8271359	
	0001000	Drain Hose	28		Clamp, Hose		8271362	
		(21 Inches)	30	3363366	Clamp, Hose	58	3366913	Clamp, Hose
		(Not Included.)	31	8317496	Clamp, Hose	59		Shield, Suds
9	3951702		32	3951449	Hose, Pump To Tub	60	3955492	Harness, Wiring
		(60 Hz.)			(Includes #30)			(For Detail See
		(Motor Not A	33	8055003	Clip, Harness			Pages 9 & 10)
		Service Part)		001011	& Pressure Hose	61	3357027	Nozzle-Drain
10	3351614		35	661614	Switch, Water	00	0047040	Hose
11		Screw 8–18 x 3/8	36	2400040	Temperature	62	8317940	Drain Hose
12		Switch, Water Level	30	3400010	Screw, Timer Mounting			Assembly
13 14		Bracket, Control Cord, Power	37	8528333	Switch, Rotary			
15		Strain Relief,	39	0020000	Panel, Console			
13	3332021	Power Cord		3955803				
		1 OWC1 COIG		3955804				
					(Includes #40)			
				3955805				
					(Includes #40)			


## **AGITATOR, BASKET AND TUB PARTS**




AGITATOR, BASKET AND TUB PARTS
For Models: LSQ9549LQ0, LSQ9549LW0, LSQ9549LG0
(Designer White) (White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1 2	63580	
2	358237	Screw & Washer (5/16-24 x 1)
3	3363003	Clothes Mover
4	3951632	Agitator
5	8528150	
6	3359585	
7	3354845	Clip, Agitator
8	3355921	Washer, Agitator
9	3951682	
10	3366877	Dog, Agitator
		Clutch
11	3952374	
		Cam
12	21366	
13	8526016	
		Ring
14	8522271	(Also Order # 14)
15	8519788	
16	63849	
17	389140	
17	303140	Drive
18	383727	
19	3347780	
		Switch
20	3951744	Agitator
		(Complete)
22	3951608	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal, Inner Cap
26	3949550	Washer

#### **MACHINE BASE PARTS**




#### BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS



### **WIRING HARNESS PARTS**

For Models: LSQ9549LQ0, LSQ9549LW0, LSQ9549LG0 (Designer White) (White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **WIRING HARNESS PARTS**


For Models: LSQ9549LQ0, LSQ9549LW0, LSQ9549LG0 (Designer White) (White/Grey) (Biscuit/Gold)

Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1 2 3 4	388498 3347812	Clip, Harness Clip, Harness Clip, Harness Clip, Harness	13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	23 24 25	60687	Connector, Etc Connector, Relay (Use Term.308569) E.T.C. Control
5		Clip, Harness	14	3347243	Block, Disconnect	26	3948617	Connector (T.P.A.)
6 7	389379	(Suds Models)	15 16		(Use Term. 352088) Protector Connector			(3-Circuit) (Lid Switch) (Use Term. 3948619
8	352090	Timer, Block Disconnect (White)	17	387566	(2-Way) (Use Term.94614) Plug, Terminal	27	3360056	OR 3948620.) Connector (T.P.A) (3–Circuit)
9	352089	Timer, Block Disconnect (Black)			(4-Way) (Power Cord) (Use M3 Screws)			(Pressure Switch) (Use Term.3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613)	18 19	3390423	Clip, Harness Block, Disconnect (12–Way) (Timer) (Use Term. 94613)	28 29	3354925 3354926	Block, Connector (Cold Valve) (Use Term.693217) Block, Connector (Hot Valve)
11	353424	Or 94614.) Plug, Terminal (3–Way) (Power Cord) (Use Term.94613)	20	3347730 388818	Receptacle (6–Way) (Use Term. 94613) Plug, Terminal (12–Way)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term.3948619
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	22	3369366	(Use Term. 94613 Or 94614.) Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)			OR 3948620.)

# FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

#### **BRAKE AND DRIVE TUBE PARTS**

For Models: LSQ9549LQ0, LSQ9549LW0, LSQ9549LG0 (Designer White) (White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION				
1	388952	Brake And Drive Tube (Complete)				
2	62658	Ring, Thrust				
3	91939	Seal, Oil				
2 3 4	356427	Seal, Drive Tube				
5	356937	Spacer, Drive				
		Tube				
6	64027	Tube, Basket				
		Drive (Includes				
		Illus. 3, 4, 5 & 9)				
7	64035	Ring, Retaining				
8	64232	Shoe, Brake				
9	62703	"T" Bearing,				
		Spin Tube				
10	62648	Cap, Brake				
		Spring (2)				
11	387806	Spring, Brake				
12	62909	Sleeve, Brake				
		Spring				
13	63023	Cam, Brake				
		Release				
14	63022	Sleeve, Cam				
15	64194	Driver, Brake				
40	00000	Cam				
16	90368	Ring, Retaining				
	FOLLOWING PARTS					

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

**NOT ILLUSTRATED** 


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **GEARCASE PARTS**

			40010	'/ .a	
; r		' 		1	
i 1	$\sim$				
¦ 2¦		<u> </u>	Illus.	Part	
! ~		!	No.	No.	DESCRIPTION
. ¦ <b>∖</b> ∟	3	!	110.	INO.	DESCRIPTION
		l			
ΙL		I	1	3360630	Gearcase (Complete)
15	23	, 1	2	285202	Cover, Gearcase
$-1 - \sqrt{ }$		<b>'</b> I	3	3349985	Seal, Gearcase
_ I _ <b>\</b> [		. 1		00=40=	Cover
-   '	7 - 24	۱ ا	4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
_		I	5	63320	Pinion, Spin
l i	8 - 25	<b>5</b> 1	-		(Includes Illus. 25)
_		1	6	356427	Seal, Spin
i	9           26	ì	7	389387	Pinion Shaft, Agitator
i	10	i	,	309301	(Complete)
'   		_ ¬;	8	90369	Ring, Retaining (2)
;		li li	9	62677	Retainer, Spring
; i	11	li	10 11	62676 63273	Spring, Agitate Gear, Agitate
		1!		03273	(Includes 15 and 29)
-	12		12	62619	Washer, Agitate
' I	13	1.	40	00500	Gear
		11	13	62580	Cam Follower (Includes 14)
	14		14	62581	Cam, Agitate
·		I <sup>1</sup>			(Includes 13)
'		11	15	285509	Shaft, Agitator
		1	16	62618	(Includes 11 and 29) Washer, Cam Thrust
1		<sub>[</sub> ]	17	16018	Bearing, Thrust
-		11	18	85529	Ball, Bearing
_   _	└ <u></u>	– <b>⊣</b> ।	19	389230	Bottom and Pinion, Gearcase
1	15	27	21	285352	Seal, Thrust Plug
l i		- ·	22	3351614	Screw, Gearcase
		1			Cover, Mounting (8)
1	16 7	98 I	23	3362552	(10–24 x 3/8) Ring, Retaining
1 1		.O i	24	285735	Washer Kit,
_ i _ !	29	i			Thrust
i	8	i	25	62570	Gear, Spin
ا ایسا		i	26 27	388253 3349296	Neutral Assembly Rack, Connecting
¦1/	<u> </u>		28	62621	Actuator, Shift
¦ 18		9 ¦	29	388815	Washer,
		9			Intermediate
	1 0 ° communa	!			
		!			
1	21	ļ			
1		l ·			
I		l			
I		I			
1	1 4 4 1	_ 1			
1	L – – – – – – GC–215	–C I			
L		. <u> </u>			

#### **WATER SYSTEM PARTS**

For Models: LSQ9549LQ0, LSQ9549LW0, LSQ9549LG0 (Designer White) (White/Grey) (Biscuit/Gold)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit
6 7	65349 367031	(Not Included) Clamp, Hose Drain Protector (Not Included)

#### **MISCELLANEOUS PARTS**

For Models: LSQ9549LQ0, LSQ9549LW0, LSQ9549LG0 (Designer White) (White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous Parts Bag
2	3976300	Washer, Inlet Hose (1–1/16 x 5/8) (4)
3	3366912	Clamp, Hose
4		Nut, Lock (3/8–16)
5	3366913	Clamp, Hose
6	389102	Foot, Front (2)

# **OPTIONAL PARTS (NOT INCLUDED)**

Illus. Part No. No. DESCRIPTION		Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH-UP (1/2oz.)	OIL			SEAL	.ER	
72017 White 4392899 Biscuit	39	50572	Oil, Gearcase (16 Oz.)		285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
PAINT, PRESSURIZED SPRAY (12 oz.)  350938 Primer, Gray 350930 White 4392901 Biscuit  PAINT, BULK (1 qt.)  799344 White (Uncut) 4392900 Biscuit (Uncut)	LUBRIC 28	<b>EANT</b> 85208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)	ACCE	367031	Y PARTS  Drain Protector Siphon Break Kit